
## CX 02 4HF/4NM HT 2 poles 40 A - 2900/5000 V



## **ASSEMBLY INSTRUCTIONS**

## CX 02 4HF/4HM



## CX 02 4HF/4HM - CONTACT HOLDER REMOVAL

